



IRN178 / IRN179 REFERENCE GUIDE

HOW TO REPLACE BROKEN BACK PLATES ON YOUR IRN78 OR IRN179

If you drop your IRN178 or IRN179 and break the back plate, it is easy to replace the part if you remember where the wires went. Use this image as a reference as to where the wires need to go. These irons would not be under warranty if dropped so this is an easy fix so you do not have to replace the whole iron.

