



GRID PLATE INSTALLATION

NOTE:

For easy and safe installation, it is best to install this Grid Plate when all steam has been shut off and the press is cold.

STEP 1:

Detach springs from worn out Grid Plate to remove from head.

STEP 2:

Clean rust off head press with a soft wire brush or hot head mitt.

STEP 3:

To install the new Grid Plate, fit plate onto press head. Place springs over the top and hook springs through eyelets to secure the Grid Plate.

STEP 4:

Bring head down and secure it by locking it. Then push and bend edge of the Grid Plate around the head. This will ensure a tight fit and will eliminate steam from escaping from the edge of the head.

NOW YOU ARE READY TO PRESS!