

HOW TO MEASURE BOILER GLASS SIZE

MEASURE FROM THE CENTER TO CENTER DIMENSIONS OF THE INSTALLED VALVES (FIGURE A). SUBTRACT 1¹/₈" FROM THAT MEASUREMENT AND SELECT THE GLASS SIZE CLOSEST TO THE FINAL MEASUREMENT.

CENTER-CENTER MEASUREMENT	STOCK#
9", 9 ¹ / ₄ "	BG10
9 ¹ / ₂ ", 9 ³ / ₄ "	BG11
10"	BG6
10 ¹ / ₄ ", 10 ¹ / ₂ "	BG1
10 ³ / ₄ "	BG7
11", 11 ¹ / ₄ "	BG2
11 ¹ / ₂ "	BG3
11 ³ / ₄ "	BG4
12", 12 ¹ / ₄ "	BG8
12 ¹ / ₂ ", 12 ³ / ₄ "	BG12
13", 13 ¹ / ₄ ", 13 ¹ / ₂ "	BG5
15 ", ¹ / ₄ , ¹ / ₂ , ³ / ₄	BG13

